

Amazon Alexa Voice Commands for Control4

Here is your personalized list of the most common voice commands that you can use to speak to your Control4 system through Alexa.

Thermostats	Commands
HVAC	Alexa, set the HVAC to 78 degrees. Alexa, raise the HVAC by 3 degrees. Alexa, lower the HVAC by 2 degrees. Alexa, what's the HVAC set to? Alexa, what's the temperature in here?

Voice Scenes	Commands
Good Bye	Alexa, turn on Good Bye. Alexa, turn off Good Bye.
Good Morning	Alexa, turn on Good Morning. Alexa, turn off Good Morning.

Lights	Commands	Room
Center & Fan	Alexa, turn on Center & Fan. Alexa, turn off Center & Fan.	Bathroom 1
Mirror	Alexa, turn on Mirror. Alexa, turn off Mirror.	Bathroom 1
Shower	Alexa, turn on Shower. Alexa, turn off Shower.	Bathroom 1
Center	Alexa, turn on Center. Alexa, turn off Center.	Bathroom 2
Fan	Alexa, turn on Fan. Alexa, turn off Fan.	Bathroom 2
Spots Bedroom 1	Alexa, turn on Spots Bedroom 1. Alexa, turn off Spots Bedroom 1.	Bedroom 1
Spots Bedroom 2	Alexa, turn on Spots Bedroom 2. Alexa, turn off Spots Bedroom 2.	Bedroom 2
Terrace lamp	Alexa, turn on Terrace lamp. Alexa, turn off Terrace lamp.	Bedroom 2
Entrance Lamp	Alexa, turn on Entrance Lamp. Alexa, turn off Entrance Lamp.	Front Door
Outdoor Spots	Alexa, turn on Outdoor Spots. Alexa, turn off Outdoor Spots.	Front Door
Spots Hallway	Alexa, turn on Spots Hallway. Alexa, turn off Spots Hallway.	Hallway First
Spots Hallway (Hide)	Alexa, turn on Spots Hallway (Hide). Alexa, turn off Spots Hallway (Hide).	Hallway First
Staircase lights	Alexa, turn on Staircase lights. Alexa, turn off Staircase lights.	Hallway First
Pendants	Alexa, turn on Pendants. Alexa, turn off Pendants.	Kitchen
Spots Kitchen	Alexa, turn on Spots Kitchen. Alexa, turn off Spots Kitchen.	Kitchen
Spots Kitchen (Hide)	Alexa, turn on Spots Kitchen (Hide). Alexa, turn off Spots Kitchen (Hide).	Kitchen
Under Cabinet	Alexa, turn on Under Cabinet. Alexa, turn off Under Cabinet.	Kitchen
Center Living	Alexa, turn on Center Living. Alexa, turn off Center Living.	Living
Entry Spots	Alexa, turn on Entry Spots. Alexa, turn off Entry Spots. Alexa, set Entry Spots to 50%. Alexa, increase Entry Spots by 20%. Alexa, decrease Entry Spots by 25%.	Living

Lights	Commands	Room
Fire Place	Alexa, turn on Fire Place. Alexa, turn off Fire Place.	Living
Living Spots (Hide)	Alexa, turn on Living Spots (Hide). Alexa, turn off Living Spots (Hide).	Living
Center & Fan	Alexa, turn on Center & Fan. Alexa, turn off Center & Fan.	Master Bathroom
Mirror Master Bath	Alexa, turn on Mirror Master Bath. Alexa, turn off Mirror Master Bath.	Master Bathroom
Shower Master Bath	Alexa, turn on Shower Master Bath. Alexa, turn off Shower Master Bath.	Master Bathroom
Center Master Bedroom	Alexa, turn on Center Master Bedroom. Alexa, turn off Center Master Bedroom.	Master Bedroom
Entry Spot Master Bedroom	Alexa, turn on Entry Spot Master Bedroom. Alexa, turn off Entry Spot Master Bedroom.	Master Bedroom
Sconces Master Bedroom	Alexa, turn on Sconces Master Bedroom. Alexa, turn off Sconces Master Bedroom.	Master Bedroom
Spots Master Bedroom	Alexa, turn on Spots Master Bedroom. Alexa, turn off Spots Master Bedroom.	Master Bedroom
Walk Out Master Bedroom	Alexa, turn on Walk Out Master Bedroom. Alexa, turn off Walk Out Master Bedroom.	Master Bedroom
Play Room Spots (Hide)	Alexa, turn on Play Room Spots (Hide). Alexa, turn off Play Room Spots (Hide).	Play Room
Spots Play Room	Alexa, turn on Spots Play Room. Alexa, turn off Spots Play Room.	Play Room
Spots Staircase	Alexa, turn on Spots Staircase. Alexa, turn off Spots Staircase.	Play Room

Locks	Commands	Room
Front Lock	Alexa, is the Front Lock locked? Alexa, lock the Front Lock	Front Door

Rooms	Commands
Bedroom 1	Alexa, turn on Bedroom 1. Alexa, turn off Bedroom 1. Alexa, mute on Bedroom 1. Alexa, unmute on Bedroom 1. Alexa, volume up on Bedroom 1. Alexa, volume down on Bedroom 1. Alexa, set volume to 20 on Bedroom 1.
Bedroom 2	Alexa, turn on Bedroom 2. Alexa, turn off Bedroom 2. Alexa, mute on Bedroom 2. Alexa, unmute on Bedroom 2. Alexa, volume up on Bedroom 2. Alexa, volume down on Bedroom 2. Alexa, set volume to 20 on Bedroom 2.
Kitchen	Alexa, turn on Kitchen. Alexa, turn off Kitchen. Alexa, mute on Kitchen. Alexa, unmute on Kitchen. Alexa, volume up on Kitchen. Alexa, volume down on Kitchen. Alexa, set volume to 20 on Kitchen.
Living	Alexa, turn on Living. Alexa, turn off Living. Alexa, mute on Living. Alexa, unmute on Living. Alexa, volume up on Living. Alexa, volume down on Living. Alexa, set volume to 20 on Living.
Master Bedroom	Alexa, turn on Master Bedroom. Alexa, turn off Master Bedroom. Alexa, mute on Master Bedroom. Alexa, unmute on Master Bedroom. Alexa, volume up on Master Bedroom. Alexa, volume down on Master Bedroom. Alexa, set volume to 20 on Master Bedroom.

Rooms

Commands

Play Room

Alexa, turn on Play Room.
Alexa, turn off Play Room.
Alexa, mute on Play Room.
Alexa, unmute on Play Room.
Alexa, volume up on Play Room.
Alexa, volume down on Play Room.
Alexa, set volume to 20 on Play Room.

If your devices change you can go to customer.control4.com to print an updated list.